



**Wand lever** 



Twist the ears






**Getting started** 

- Your Turtle®Vac comes with a bag fitted, so it's all ready to get to work
- Screw on the hose, attach the metal telescopic wand and push on your chosen tool for floors, stairs, crevices or dusting
- Slide the lever on the telescopic metal wand to adjust to the most comfortable height
- Twist the 'ears' of the handle inwards to release the cable
- Choose level of suction. I is for full power,
  Il is for energy-saving eco-power.
  You can also reduce the power by sliding open the shutter vent on the wand
- Plug in the socket and press the kick switch lightly with your foot to switch on
- Move the wand lightly over the carpet no pressure is needed
- When the bag is full, open the lid by pushing up the three snap fasteners. Carefully remove the full dust bag and push a new one firmly onto the pipe. Replace the lid and secure with the three snap fasteners
- To purchase more bags, visit our website www.turtlemat.co.uk or phone 0845 600 3478.

## **Service contact details**

Customer Services 0845 600 3478 or email turtlematcustomerservices @braywood.co.uk











Pure-air filte



Check nose



Check inside

## Caring for your Turtle®Vac

- To keep your Turtle Vac at peak performance, clean the pure-air drum filter regularly by removing it and giving it a shake
- If your Turtle Vac or its tools need a clean, simply wipe with a damp cloth
- If your Turtle Vac loses suction check that the tools, hose and wand are free from blockages and that the bag is not full or split
- Check that the pure-air drum filter inside the drum is clean and that the rubber lip is tightly sealed against the drum
- Your Turtle Vac has a safety thermal cut-out to prevent overheating so blockages or clogged filters may make it stop working for a short time. If this happens, remove the plug from the socket, remove the bag, clean and replace the pure-air drum filter and put back bag. Wait for five minutes then re-start
- In the unlikely event that your Turtle Vac stops working please refer to your manual or contact our customer services.



## **Service contact details**

Customer Services 0845 600 3478 or email turtlematcustomerservices @braywood.co.uk





